

1st January 2021

DF95

TUNING GUIDE

Phil Burgess Sydney, Australia -
0413 200 608 philb@psk.com.au

MAST

Bow
Bumper-hull joint to front crane hole (mm)

Gate
Position (0 at front)

HEADSAIL

Foot
Depth (mm)

Boom
Angle - boom to mast centre (mm)

Twist - mid leech to mast (mm)

MAINSAIL

Foot
Depth (mm)

Cun'ham - downhaul pressure

Boom
Angle - boom to centre line (mm)

Twist - middle batten to backstay (mm)

These baseline settings need to be adjusted depending on the weather conditions for each race

A	Base	1135	5	25	55	60	30	None	35	60
	Light Winds & Flat Water	1131	4	28	45	50	30	None	40	45
Small Waves	1136	6	25	35	50	25	None	15	45	
Big Waves	1133	7	30	50	75	40	None	33	65	
B	Base	980	5	30	40	45	30	Slight	20	55
	Small Waves	980	6	30	38	32	30	Slight	20	45
	Big Waves	970	4	28	50	60	30	Slight	23	70
C	Base	855	8	15	60	65	35	Firm	20	45
	Small Waves	850	8	15	40	25	20	Firm	15	45
	Big Waves	845	8	30	50	50	35	Firm	25	50
D	Base	790	8	15	60	65	35	Firm	20	45
	Small Waves	793	8	15	60	70	30	Firm	20	45
	Big Waves	793	8	15	55	75	20	Firm	25	55